









▲ kit de mise à niveau / upgrade kit



Indique un choix à faire selon X X X.
Indicates a choice to be made according to X X X.

X X X	A	B	C	V
482	Aa	Ba	Ca	Va
569	Ab	Bb	Cb	Vb

L'ancien variateur n'est plus disponible, pour le remplacer commander le **kit de mise à niveau Va**.
Vous recevrez le nouveau variateur Vb, le socle Bb, la carte boutons Cb, le support variateur 36, les vis et la notice.
Si vous avez déjà remplacé votre variateur par un nouveau, passez à la colonne 569.

The old variator is no longer available, to replace it, order the **upgrade kit Va**. You will receive the new variator Vb, the base Bb, the controls board Cb, the variator support 36, the screws and the technical instructions.
If you have already changed your variator by a new one, use column 569.

Index	Reference	Article	Pricings
1	27414	R602 CUTTER	Contact us
2	29341	R502 CUTTER LID	Contact us
3	117100S	LID SEAL R502/R602	Contact us
4	117320	BLADE DISMANTLING TOOL	Contact us
5	101845S	MINI BOWL BLADE TOOL	Contact us
6	49435	CUTTER BOWL ASSEMBLY R6-R602-R652-R7-R752	Contact us
7	27124	COMPLETE SMOOTH BLADE CR R602	Contact us
8	49161	UPPER STRAIGHT BLADE R602	Contact us
9	49160	LOWER STRAIGHT BLADE R602	Contact us
10	27125	COMPLETE SERRATED BLADE R602	Contact us
11	49163	UPPER SERRATED BLADE R602	Contact us
12	49162	LOWER SERRATED BLADE R602	Contact us
13	27352	R602 FINE SERRATED BLADE	Contact us
14	49165	UPPER FINE SERR BL R602	Contact us
15	49164	LOWER FINE SERR BL R602	Contact us
16	102073	BLADE LOCKING NUT R602	Contact us
17	117031	PLASTIC SPACER 5MM R602	Contact us
18	39835	S/S RING ASSEMBLY R602E	Contact us
19	117029	LOWER SPACER R602	Contact us
20	103904	BLADE SUPPORT R602 2P	Contact us
21	39827	SPRING CATCH ASSY R502E	Contact us
22	39828	MOTOR SUPPORT ASSY 602VVE	Contact us
23	29586	REED SWITCH ASS R602VVA	Contact us
24	29336	BOWL SUPPORT ASSY (X2)	Contact us
25	39277	VEGETABLE SLICER SAFETY SWITCH ASSY R602VVA	Contact us
26	39815	FRONT PLATE ASSY R602VVE	Contact us
27	502171S	PULSE BUTTON	Contact us
28	502170S	GREEN KNOB	Contact us
29	502169S	RED KNOB	Contact us
30	117073S	POTENTIOMETER HANDLE	Contact us
31	39202	R402VV POTENIOMETER ASSY	Contact us
32	29533	PCB SUPPORT ASSEMBLY	Contact us
34	29903	FIXING KEY (X2)	Contact us

Index	Reference	Article	Pricings
35	117705S	AIR FLOW SEPARATOR	Contact us
36	39973	VARIATOR SUPPORT R6VV	Contact us
37	103905	R602 VV BAFFLE	Contact us
38	49242	SECURITY PIN + NUT ASSEMBLY RANGE 6	Contact us
39	39088	SOCKET SUPPORT SEAL ASSY	Contact us
40	501624S	LIP SEAL 6/6,5	Contact us
41	27340	VEGETABLE SLICER ATTACHMENT R502E/R602E	Contact us
42	39821	VEGETABLE SLICER LID ASSY R502E	Contact us
43	39824	PUSHER GUIDE+AXLE R502E	Contact us
44	39704	GUIDE AXLE ASSEMBLY CL50E	Contact us
45	39826	PUSHER GUIDE R502E	Contact us
46	100638S	PUSHER GUIDE RING	Contact us
47	39701	VEGETABLE PUSHER ASSY	Contact us
48	117452S	HANDLE PUSHER CL50E/GOUR	Contact us
49	118324S	CL50D ROUND PUSHER	Contact us
50	39705	SHOULDERED RINGS (x2)	Contact us
51	39823	LID+ROD ASSY CL50E/R502E	Contact us
52	29501	CLINCH CLIP ASSY (x2)	Contact us
53	39820	VEGETABLE SLICER BOWL ASSY R502/R602E	Contact us
54	102690S	GREY SLING PLATE CL50D	Contact us
55	29058	SHOULDERED RING (x2)	Contact us
56	29061	LOCKING ROD ASS	Contact us
57	39834	VEG LOCKING PLATE ASSY	Contact us
58	118433S	FIXING STAR	Contact us
59	110308S	MOTOR SHAFT PIN	Contact us
60	303009	MOTOR R602 VV	Contact us
61	39819	BEARING ASSY R502/602	Contact us
62	105885	MOTOR FAN LS R502/602	Contact us
63	507343S	STRAIN RELIEF	Contact us
64	39833	GREY FOOT R502/R602-J80-J100 GRIS (X4)	Contact us
65	49114	BLADE UPGRADE KIT R602	Contact us
66	49115	R602 BLADE LOCKING NUT ASSEMBLY	Contact us
67	49117	STAINLESS STEEL RING H15MM ASSEMBLY	Contact us
68	49119	LOWER AND UPPER SPACER ASSEMBLY	Contact us
69	59542	BASE SCREWS ASSEMBLY 5-6L	Contact us

Index	Reference	Article	Pricings
70	59623	FIXING STAR ASSEMBLY R502D	<i>Contact us</i>
71	29901	BLADE TOOL ASSY RANGE 5-7	<i>Contact us</i>
Ab	39978	POWER CORD R6VVA EUR	<i>Contact us</i>
Bb	59192	BASE ASSEMBLY R502/R602 PA30%FDV	<i>Contact us</i>
Cb	39977	CONTROL BOARD RANGE 5-6 VVE	<i>Contact us</i>
Vb	39972	VARIATOR ASSEMBLY R4/R6VV	<i>Contact us</i>